

### Removal


---

1 Remove instrument cluster (54–250).

2 Pull off electrical connection.

3 Unscrew the 4 fastening screws (1).

4 Remove time clock.




154-23199

### Installation

---

5 For installation proceed vice versa.



154-14180